

FLAGSTONE PAVING SET ON DECOMPOSED GRANITE



MATERIALS

- * Decomposed Granite
- * Flagstone
- * Level
- * Tamper
- * Small Sledge Hammer
- * Safety Goggles

DIRECTIONS

1. Dig out native soil so that depth of decomposed granite plus height of flagstone will be flush with top of edging / existing paving.
2. Level out native soil and tamp down for a firm base.
3. Spread 1" of decomposed granite on top of native soil, tamp down.
4. Spread another 1" layer of decomposed granite and tamp down.
5. Check thickness of stone and add more decomposed granite if necessary, tamp down.
Note: Top of flagstone should be flush with existing sidewalks.
6. Place stones and wiggle into decomposed granite so they are embedded.
Try to maintain uniform joint spacing of about 1".
7. Larger flagstone pieces are easily broken by tapping with a small sledgehammer.
Note: The larger the piece of flagstone the more stable the paving area. Do not break if not necessary.
8. Back fill joints with decomposed granite.